



**HEAD FLASHING TIE-IN INSTRUCTIONS:**

1. Cut, fold up & temporarily secure weather resistive barrier above header to allow for flashing installation
2. Self-adhered flashing plus head flashing under weather resistive barrier
3. Fold weather resistive barrier back over head flashing and seal with tape

**SCS 06\_04 SELF-ADHERED FIN FLASHING  
(AFTER WEATHER RESISTIVE BARRIER)**

Note:  
Details to be used in conjunction with all applicable provisions contained in the Sealed Cladding System Design Manual.

Sealed Cladding System

07/01/2020

SCS 06\_04